Fundamentals of Electric Circuit

Chapter -12

Three-Phase Circuits

CHAPTER 12 THREE-PHASE CIRCUITS (三相电路)

1. Introduction


Thomas Alva Edison (1847-1931)




A balanced three-phase system is produced by a generator consisting of three sources having the same amplitude and frequency but out of phase with each other by 120° .

Three-phase systems are important for at least three reasons:


- Nearly all electric power is generated and distributed in three-phase.
- The instantaneous power in a three-phase system can be constant.
- For the same amount of power, the three-phase system is more economical than the single-phase.

























Chapter 12 Three-Phase Circuits


- 12.1 Basic concepts of three-phase circuit
- 12.2 Analysis of the Wye-Wye (Y-Y) Circuit
- 12.3 Analysis of the Wye-Delta (Y-△) Circuit
- 12.4 Balance Delta-delta Connection
- 12.5 Balance Delta-Wye Connection
- 12.6 Summary of Balance Connection
- 12.7 Power in Balance System
- 12.8 UnBalance three-phase System


Chapter Contents


- 1. Basic concepts of three-phase circuit
- 2. Analysis of the Wye-Wye (Y-Y) circuit
- 3. Analysis of the Wye-Delta (Y-△) circuit


Chapter Objective


- •Learning the distinction between single-phase and polyphase systems
- ullet Becoming familiar with working with both Y- and \triangle -connected three-phase sources
- ullet Becoming familiar with working with both Y- and \triangle -connected networks
- Mastering the technique of per-phase analysis of threephase systems
































Apply the nodal analysis and select the node N' as reference node, we have

$$\dot{U}_{NN'} = \frac{\dot{U}_a/Z + \dot{U}_b/Z + \dot{U}_c/Z}{1/Z + 1/Z + 1/Z} = \frac{1}{3}(\dot{U}_a + \dot{U}_b + \dot{U}_c) = 0$$


Thus we can also get the following equivalent circuit








Thus we can get the following equivalent circuit





 $\label{eq:Athree-phase circuit changes into three single phase circuits now. \\$


(一个三相电路→ 三个单相电路)


It is easy to find phase currents and phase voltage.


















The phasor diagram for this circuit is shown in following Fig.



Once we knew any of the line voltage magnitudes and any of the line current magnitudes, the angles for all three voltages and all three currents could have been easily obtained by reading the diagram.

showing that the line voltages are equal to the voltages across the load impedances for this system configuration. From these voltages, we can obtain th phase currents as

$$\dot{I}_{a} = \frac{\dot{U}_{AB}}{Z_{a}} = \frac{\dot{U}_{AB}}{Z} \qquad \qquad \dot{I}_{b} = \frac{\dot{U}_{BC}}{Z_{c}} = \frac{\dot{U}_{AB} \angle - 120^{o}}{Z} \qquad \qquad \dot{I}_{c} = \frac{\dot{U}_{CA}}{Z_{b}} = \frac{\dot{U}_{AB} \angle 120^{o}}{Z}$$

These currents have the same magnitude but are out of phase with each other by 120°.


The line currents are obtained from the phase currents by applying KCL at nodes A,B, and C. Thus

$$\dot{I}_A = \dot{I}_a - \dot{I}_c$$
 $\dot{I}_B = \dot{I}_b - \dot{I}_a$ $\dot{I}_C = \dot{I}_c - \dot{I}_b$

$$= \sqrt{3}\dot{I}_a \angle -30^o \qquad = \sqrt{3}\dot{I}_b \angle -30^o \qquad = \dot{I}_c \angle -30^o$$

12.3 Analysis of the Wye-Delta (Y-△) Circuit

The balanced Y- Δ system consists of a balanced Y-connected source feeding a balanced Δ -connected load. The balanced Y- Δ system is shown following the figure.



Assuming the positive phase sequence, the phase voltages are again

$$\dot{U}_a = U_p \angle 0^o$$
 $\dot{U}_b = \dot{U}_a \angle -120^0$ $\dot{U}_c = \dot{U}_a \angle +120^0$

The line voltages are

$$\dot{U}_{ab} = \sqrt{3}\dot{U}_{a} \angle 30^{o} = \dot{U}_{AB} \quad \dot{U}_{bc} = \sqrt{3}\dot{U}_{b} \angle 30^{o} = \dot{U}_{BC} \qquad \dot{U}_{ca} = \sqrt{3}\dot{U}_{c} \angle 30^{o} = \dot{U}_{CA}$$


Showing that the magnitude of I_L of the line current is $\sqrt{3}$ Times the magnitude I_n of the phase current, or


$$I_L = \sqrt{3}I_p$$


where


$$I_L = \left| \dot{I}_A \right| = \left| \dot{I}_B \right| = \left| \dot{I}_C \right| \qquad \qquad I_P = \left| \dot{I}_a \right| = \left| \dot{I}_b \right| = \left| \dot{I}_c \right|$$


Also, the line currents lag the corresponding phase currents by 30° .














Connection	Phase voltages/ Currents	Line voltages / Currents
Υ-Δ	$\dot{U}_{an} = U_p \angle 0^\circ$	$\dot{U}_{ab} = \dot{U}_{AB} = \sqrt{3}U_p \angle 30$
	$\dot{U}_{bn} = U_p \angle -120^{\circ}$	$\dot{U}_{bc} = \dot{U}_{BC} = \dot{U}_{ab} \angle -$
	$\dot{U}_{cn} = U_p \angle 120^\circ$	$\dot{U}_{ca} = \dot{U}_{CA} = \dot{U}_{ab} \angle -$
	$\dot{I}_{AB} = \dot{U}_{AB} / Z_{\Delta}$	$\dot{I}_A = \sqrt{3}\dot{I}_{AB} \angle -30^\circ$
	$\dot{I}_{BC} = \dot{U}_{BC} / Z_{\Delta}$	$\dot{I}_B = \dot{I}_A \angle -120^\circ$
	$\dot{I}_{CA} = \dot{U}_{CA} / Z_{\Delta}$	$\dot{I}_C = \dot{I}_A \angle 120^\circ$

Summary of phase and line voltages/ currents for balanced three-phase systems			
Connection	Phase voltages/ Currents	Line voltages / Currents	
Δ-Δ	$\dot{U}_{ab} = U_p \angle 0^\circ$	Line voltages are the same as phase voltages	
	$\dot{U}_{bc} = U_p \angle -120^\circ$ $\dot{U}_{cc} = U_p \angle 120^\circ$	$\dot{I}_A = \sqrt{3}\dot{I}_{AB} \angle -30^\circ$	
	$\dot{I}_{AB} = \dot{U}_{ab} / Z_{\Delta}$	$\dot{I}_B = \dot{I}_A \angle -120^\circ$	
	$ \dot{I}_{BC} = \dot{U}_{bc} / Z_{\Delta} \dot{I}_{CA} = \dot{U}_{ca} / Z_{\Delta} $	$\dot{I}_C = \dot{I}_A \angle 120^\circ$	

Summary of phase and line voltages/ currents for balanced three-phase systems			
Phase voltages/ Currents	Line voltages / Currents		
$\dot{U}_{ab} = U_p \angle 0^\circ$	Line voltages are the same as phase		
$\dot{U}_{bc} = U_p \angle -120^\circ$	voltages		
$\dot{U}_{ca} = U_p \angle 120^\circ$	$\dot{I}_{A} = \sqrt{3}\dot{I}_{AB} \angle 30^{\circ}$		
Phase currents are the same as line currents	$ \dot{I}_B = \dot{I}_A \angle -120^\circ \dot{I}_C = \dot{I}_A \angle 120^\circ $		
	Phase voltages/ Currents $\dot{U}_{ab} = U_p \angle 0^\circ$ $\dot{U}_{bc} = U_p \angle -120^\circ$ $\dot{U}_{ca} = U_p \angle 120^\circ$ Phase currents are the same as line		

The total instantaneous power in the load is the sum of the instantaneous powers in the three phases; that is,

$$p = p_a + p_b + p_c = u_{AN}i_A + u_{BN}i_B + u_{CN}i_C$$

$$p = 2U_p I_p [\cos \omega t \cos(\omega t - \theta) + \cos(\omega t - 120^\circ) \cos(\omega t - \theta - 120^\circ) + \cos(\omega t + 120^\circ) \cos(\omega t - \theta + 120^\circ)]$$

Applying the trigonometric identity

$$\cos A \cos B = \frac{1}{2} [\cos(A+B) + \cos(A-B)]$$
 gives

$$p = U_p I_p [3\cos\theta + \cos(2\omega t - \theta) + \cos(2\omega t - \theta - 240^\circ) + \cos(2\omega t + 240^\circ)]$$

$$= U_p I_p [3\cos\theta + \cos(2\omega t - \theta) + \cos(2\omega t - \theta)\cos 240^\circ + \sin(2\omega t - \theta)\sin 240^\circ + \cos(2\omega t - \theta)\cos 240^\circ - \sin(2\omega t - \theta)\sin 240^\circ]$$

12.7 Power in Balance System

Let us now consider the power in a balanced three-phase system. Examine the instantaneous power absorbed by the load.

For a Y-connected load, the phase voltages are

$$u_{AN}(t) = \sqrt{2}U_{P}\cos\omega t$$
 $u_{BN}(t) = \sqrt{2}U_{P}\cos(\omega t - 120^{\circ})$

$$u_{CN}(t) = \sqrt{2}U_P \cos(\omega t + 120^\circ)$$

If $~Z_{_Y}=Z \, \angle \, \theta~$, the phase currents lag behind their corresponding phase voltages by $\theta.$ Thus

$$i_A(t) = \sqrt{2}I_P \cos(\omega t - \theta) \ i_B(t) = \sqrt{2}I_P \cos(\omega t - \theta - 120^\circ)$$

 $i_B(t) = \sqrt{2}I_P \cos(\omega t - \theta + 120^\circ)$

Where I_n is the effective value of the phase current.

$$p = U_p I_p [3\cos\theta + \cos(2\omega t - \theta) + 2\cos(2\omega t - \theta)\cos 240^\circ]$$

$$= U_p I_p [3\cos\theta + \cos(2\omega t - \theta) - 2(-\frac{1}{2})\cos(2\omega t - \theta)]$$
$$= 3U_p I_p \cos\theta = \sqrt{3}U_L I_L \cos\theta$$

1, average power

$$P = P_A + P_B + P_C = U_A I_A \cos \theta_A + U_B I_B \cos \theta_B + U_C I_C \cos \theta_C$$

Balanced three phase system:

$$P = 3U_p I_p \cos \varphi = \sqrt{3}U_l I_l \cos \varphi$$

2, reactive power

$$Q = Q_A + Q_B + Q_C = U_A I_A \sin \varphi_A + U_B I_B \sin \varphi_B + U_C I_C \sin \varphi_C$$

Balanced three phase system:

$$Q = 3U_p I_p \sin \varphi = \sqrt{3}U_l I_l \sin \varphi$$

3. apparent power $S = \sqrt{P^2 + Q^2}$


Balanced three phase system:

$$S = 3U_p I_p = \sqrt{3}U_l I_l$$

4, complex power

$$\tilde{S} = 3\dot{U}_n \dot{I}_n^* = P + jQ = \sqrt{3}U_I I_I \angle \theta$$

- 5. Measurement of a power
- A. Use of the Wattmeter




(*) A wattmeter connection that will ensure an upscale reading for the power absorbed by the passive network.


- •To be specific, let us assume that we are measuring the power absorbed by a passive network.
- •The current coil is inserted in series with one of the two conductors connected to the load, and the potential coil is installed between the two conductors, usually on the "load side" of the current coil.
- The potential coil terminals are often indicated by arrows. Each coil has two terminals, and the proper relationship between the sense of the current and voltage must be observed.

Use of the Wattmeter

- •The wattmeter is used by connecting it into a network in such a way that the current flowing in the current coil is the current flowing into the network and the voltage across the potential coil is the voltage across the two terminals of the network.
- The current in the potential coil is thus the input voltage divided by the resistance of the potential coil.
- •It is apparent that the wattmeter has four available terminals, and correct connections must be made to these terminals in order to obtain an upscale reading on the meter.

- •One end of each coil is usually marked (+), and an upscale reading is obtained if a positive current is flowing into the (+) end of the current coil while the (+) terminal of the potential coil is positive with respect to the unmarked end.
- •The wattmeter shown in the network of the Fig.(*), therefore gives an upscale deflection when the network to the right is absorbing power. A reversal of either coil, but not both, will cause the meter to try to deflect downscale; a reversal of both coils will never affect the reading.








12.8 UnBalance three-phase System

An unbalanced system is due to unbalanced voltage sources or an unbalanced load. Generally, the source voltage is balanced, but the load is unbalanced.

Unbalanced three-phase system are solved by direct application of mesh and nodal analysis.









 $\dot{U}_{NN'} = 61.27 \angle 115.76^{\circ}V$ $\dot{U}_{AN} \approx 253 \angle -13^{\circ}$

 $U_{BN} \approx 260 \angle -109^{\circ}$

 $\dot{U}_{\it CN} \approx 159 \angle 122^{\circ}$

•From the phasor diagram, we know that the voltage between the neutral point of the source and the neutral of the load does not equal zero, because of the absence of neutral line, and results in unbalanced phase voltages.

•Therefore, in the three-phase four-wire system, the neutral line has large diameter, and it does not connect to the switch and fuse-element

Summary

- •The phase sequence is the order in which the phase voltages of a three-phase generator occur with respect to time. In an *abc* sequence of balanced source voltages, \dot{U}_{an} leads \dot{U}_{bn} by 120°, which in turn leads \dot{U}_{ca} by 120°. In an *acb* sequence of balanced source voltages, \dot{U}_{an} leads \dot{U}_{ca} by 120°, which in turn leads \dot{U}_{cb} by 120°.
- •A balanced wye-or delta-connected load is one in which the three-phase impedances are equal.
- •The easiest way to analyze a balanced three-phase circuit is to transform both the source and the load to Y-Y system and then analyze the single-phase equivalent circuit.
- •The line current I_L is the current flowing from the generator to the load in each transmission line in a three-phase system. The line voltage U_L is the voltage between each pair of lines, excluding the neutral line if it exists. The phase voltage U_p is the voltage of each phase. For a wye-connected load.

 $U_{L} = \sqrt{3}U_{P}, \quad I_{L} = I_{P}$ For a delta-connected load

$$U_L = U_P$$
, $I_L = \sqrt{3}I_P$

- •The total instantaneous power in a balanced three-phase system is constant and equal to the average power.
- •The total complex power absorbed by a balanced three-phase Y-connected or $\Delta\text{-connected load}$ is $\tilde{S} = P + jQ = \sqrt{3}U_{L}I_{L}\angle \Theta \text{where } \Theta \text{is the angle of the load impedances}.$
- •An unbalanced three-phase system can be analyzed using nodal or mesh analysis.
- •The total real powr is measured in three-phases using either the three-wattmeter method or the two wattmeter method